

# Antibacterial sticky mat

## Self-adhesive

- Anti-bacterial protection
- Instant renewed protection
- Easy mounting without frame
- Ideal for healthcare & food industry

### How to Install Sticky Mats

#### Prepare the Area Where the Mat Will Be Placed

1. Select a hard, flat, dry, smooth, and clean surface. Mats should be room temperature before installing, as cold temperatures will affect the adhesive properties.
2. Clean the placement area, removing any residue and dirt from the placement area. We recommend using 70% Isopropyl Alcohol and a heavy duty low lint wipe or cloth to remove any previously existing adhesive or grime.

#### Install the Mat

3. Remove mat bottom protective film gradually. Starting with the easy peel off tab, peel off the backing to expose 2-3" of the adhesive.

**DO NOT** accidentally also remove the bottom sheet of the mat (as this will remove your mat to floor adhesion layer).

4. Adhere the edge with the exposed adhesive to the floor, taking care to avoid air bubbles.
5. Once you've ensured the adhered edge is flat and straight, slowly press the rest of the mat to the floor, working from the front edge towards the back. Use your hand, a cloth, or an empty cardboard tube to press and remove any air bubbles.
6. After the entire mat is in contact with the floor surface. Walk on the mat (while top protective film is still attached), to apply additional pressure and ensure full mat surface is securely affixed to floor. Pay special attention that corners & edges are affixed correctly to the floor and smooth out any air bubbles.

#### Peel off Mat Sheet

Peel off mat top protective film The Sticky Mat is now ready for use.

To change a mat sheet, peel off the top dirty sheet to expose the next clean sheet below. The proper way to remove a contaminated sheet is to roll it up on itself. Our recommendation is to start at the tabbed corner, pull the sheet gradually towards the middle of the mat, rolling the sheet into a ball as you go. This way, it helps to avoid generating a static charge and releasing particles.

### How are Sticky Mats Stored and Transported?

#### Storage

As sticky mats are extremely thin, they are easy to wrinkle and go out of shape. Therefore we should be very careful when keeping them in storage. It is strongly recommended to store sticky mats in their original package as well as on the original shipping pallet. Cool, dry place which has good ventilation is preferred. Remember to keep them flat, do not bend, and stay away from moisture and flame. Meanwhile, it's better not to expose them to direct sunlight for a long time. Before using sticky mats, they should be stored flat for several hours in an environment which has similar temperature as the application scenario they are intended for.

If stored properly, sticky mats will function just as well for up to three years. But we would not suggest that they be kept too long. It's best to consume them within one year, counting from the date of purchase.

#### Transportation

When customer order many boxes of sticky mats, we would recommend to put them on pallet for transportation. Be careful to handle it gently during loading and discharging operations. As sticky mats are extremely thin, in order to keep them in good condition, no heavy cargo is allowed to stack upon the pallet.

If ordering quantity is not big enough for a pallet for instance, one or several boxes reinforce with hard boards (plywood) at each side, then pack with stretch film. Remember to keep the package flat during the whole transportation process.

